

## **Installation Instructions for Wainscoting Panel**



- 1. Before starting the installation, surface must be dry, smooth and free from dust, grease, wax, and other particles\*.
- 2. Measure the area to be covered to determine how many panels you will need.
- 3. Wainscot Wall panels should be installed from left to right, making sure the small flats of the panel are to the top and right (if your panel has Built-in-Overlap or BIO). After applying your selected adhesive to the wall, according to manufacturer's instructions, lay up your first tile applying pressure as you hold it (if your panel came with protective masking, gently remove it now). Make sure the panel is straight before you continue with the next one.
- 4. Repeat this process, working left to right (removing the protective masking after installing each panel, if your tile came with masking). When finished, use the paint roller on an extension pole to apply additional pressure to the wall.

<sup>\*</sup> The method you choose for cleaning prior to application must be compatible with the surface you are cleaning (e.g. denatured alcohol, degreaser, soap & water, TSP, Greased Lightning, etc.). Check the manufacturer's label directions for instructions on using the product.