



Installation Instructions:



1

1. Clean the door frame with mild soap and water to remove any dust or debris. Allow the doorframe to dry before installing the screen.



2

2. Lay the screen flat on the floor with the (fuzzy side) hook and loop tape facing up.



3

3. Apply the supplied adhesive backed hook and loop tape strips to the top and sides of the screen. Be careful not to remove the white paper backing yet.



4

4. Starting with the top, peel off the white paper backing from the hook & loop tape. Adhere the screen to the door frame working outward from the top center. It is important that the screen is slightly higher at top center



5

5. Once the top of the screen is in place, slowly peel off the white paper backing from the sides working from top to bottom. Press firmly all the way down. Make sure your screen door opens and closes properly. Make adjustments if necessary.

Enjoy your Fenestrelle Magnetic Screen Door!

Check Out Our Other Great Products!



**Adjustable
Window Screen**



www.fenestrelleproducts.com
140 Central Ave.
Farmingdale, NJ 07727
888-223-3050



**Magnetic
Screen Door**