
Prepare your surface before coating


PREP

UNCOATED WOOD OR CONCRETE*



























*See product label for more details

Project Checklist

1/2" Nap Roller Cover (for Smooth & Textured finish

Extra Textured Roller Cove (for Extra Textured finish)

Painter's Tape

Roller Frame & Extension Pole Stir Stick & Paint Tray

Drop Cloth

Nylon/Polyester Brush

Protective Equipment (gloves, goggles, etc) Plastic Watering Can

Stiff Bristle Brush

Hose or Pressure Washer

Wood or Concrete Cleaners Concrete Surfaces:
Paint Stripper to Remove
Failing Coating (if necessary)

Wood Surfaces:
Stripper such as BEHR PREMIUN
Wood Stain & Finish Stripper
to Remove Failing Coating
(if necessary)

COVER IMAGE deck: CHOCOLATE SC-129 Find Us On: behr.com

C-DECK-OVER Item No. 50003180 09/24 Have a coating or product question?

Visit behr.com or call 1-800-854-0133 (U.S.)











ADVANCED DECKOVER®

PRODUCT & COLOR GUIDE



SMOOTH, TEXTURED, OR EXTRA TEXTURED FINISH

RESURFACES PROPERLY PREPARED WEATHERED WOOD & CONCRETE

Choose your color and finish

ADVANCED DECKOVER® RESURFACES PROPERLY PREPARED WEATHERED WOOD AND CONCRETE



ADVANCED DECKOVER

- Creates a smooth, waterproofing finish
- Conceals splinters & cracks up to 1/4"



ADVANCED DECKOVER

- Creates a textured, waterproofing finish
- For an extra textured finish, use the Extra Textured Roller Cover





★ Popular Color