



Composite Edging with Depth Indicator

Borde de material compuesto con
indicador de profundidad

INSTALLATION INSTRUCTIONS:

1. Using a rope or hose, create a layout for your edging project.



2. Using a spade or shovel create a "V" in the ground along the intended line 4-5 in deep.



3. Install the edging by aligning the green line with the ground line leaving approximately 3/4 in above the ground. This will create an effective root barrier while reducing interference with lawn equipment.



4. Secure edging using metal stakes placed every 4-5 ft.



5. Connect 20 ft lengths by overlapping 6 in and secure with two metal stakes.



Instrucciones de instalación:

1. Usando una soga o manguera, crea un diseño para tu proyecto de borde.

2. Usando una azada o pala, crea una "V" en la tierra guiándote por la línea para ese fin, de 10.1 a 12.7 cm de profundidad.

3. Instala el borde alineando la línea verde con la línea en la tierra, dejando aproximadamente 1.9 cm por encima de la tierra. Esto creará una barrera efectiva para las raíces, reduciendo la interferencia con los equipos para césped.

4. Asegura el borde usando estacas de metal, colocándolas cada 1.21 a 1.52 m.

5. Conecta largos de 6.1 m, superponiendo 15.2 cm, y asegura con dos estacas de metal.

Made from Recycled Materials
Elaborado con materiales reciclados