

Cutting Lattice:



We recommend using a 6½" or 7¼" (140 tooth) circular saw blade "for plywood/plastics/laminates" to cut lattice.

Place a 2x4 or 2x6 piece of lumber on your cutting surface. Rest the lattice sheet on top of the lumber, positioning it with the marked line facing upward right next to the wood.

Set the depth of the circular saw blade roughly ½" deeper than the thickness of the lattice.

Let the blade come to full speed and cut slowly. Use 120-grit sandpaper to clean off any residual plastic on the cut edge.