

Amamoi Pergola Bracket Kit – Installation Guide

Contents: - 2 Four-Way Pergola Brackets
- 48 Drill Tail Screws (M4.8 × 50 mm)
- Installation Guide

Tools Needed (Not Included): - Drill/Driver
- Measuring Tape
- Level
- Pencil/Marker
- Wrench (optional)

Step 1 – Prepare Wooden Posts

1. Select posts suitable for your project (pergola, gazebo, patio).
2. Cut posts to desired length. Ensure ends are straight and smooth.

Step 2 – Position Brackets

1. Place the bracket on top of the post or at the corner joint.
2. Ensure the bracket fully covers the post for maximum support.
3. Align bracket to desired orientation and mark screw positions.

Step 3 – Secure Brackets

1. Using the included drill tail screws, attach the bracket to the post.
2. Drive screws evenly and fully, ensuring the bracket sits flush against the wood.

Step 4 – Assemble Beams

1. Insert horizontal beams into the bracket slots.
2. Adjust alignment using a level to ensure beams are straight and square.
3. Secure beams with screws provided.

Step 5 – Attach Accessories (Optional)

1. Use pre-drilled grommet holes for sunshade sails or other accessories.
2. Ensure attachments are secure and evenly distributed.

Step 6 – Final Inspection

1. Check all screws and brackets for tightness.
2. Ensure posts and beams are level and stable.
3. Confirm the structure is ready for outdoor exposure.

- Safety Notes:** - Wear safety gloves and eye protection during installation.
- Avoid over-tightening screws to prevent wood splitting.
 - Inspect periodically to ensure long-term stability.