

Installation and Care Instructions

Installing Timberchic is a fun experience that even the most novice DIYers can enjoy. Don't overthink the project and let your creative side show while transforming your space. We encourage you to consider the below steps when installing your Timberchic wall planks.

1. Allow your planks to acclimate out of the box in the room you plan to install in for at least 3 days.
2. Be sure to clean your surface and allow time to dry prior to applying your wall planks. The surface must be free of dust or debris prior to application.
3. When installing Timberchic we strongly encourage the use of a J-Roller. Be sure to apply strong pressure to the planks to allow for proper adhesion of the tape to your surface.
4. A super tight application is not ideal. A minimal amount of space between rows will allow for expansion and slight movement of the wood. This experience occurs even more during the times of great humidity.
5. Last and most important, have fun and enjoy the process of reclaiming your space with the best wooden wall plank on the market!