



Installation Instructions

1. Remove Panel/Valance from packaging
2. Iron on low setting to remove wrinkles and to straighten
3. Now you are ready to hang curtains on the window hardware
 - A. Rod Pocket – Feed curtain rod thru rod pocket on top of curtain
 - B. Grommet Panels – Feed curtain rod thru metal grommets
 - C. Hang Panels/Valance