

INSTRUCTION GUIDE

KITCHEN P-TRAP



1 Measure and cut the wall tube to desired length.

2 Position the slip nuts and slip washers onto the wall tube.

3 Insert the wall tube into the waste connector and hand tighten the existing waste connector slip nut.

4 Position the slip nut and slip washer onto the vertical tailpiece.

5 Place J-bend onto the wall tube and tailpiece, and hand tighten the slip nuts for alignment.

6 Fully tighten all slip nuts and test for leaks.

