

1



Slide mirror portion straight up from base

2



Hold the mirror portion with water reservoir and fill with warm water from your shower

3



Slide mirror portion back down

**Your
Z'Fogless
Mirror is
ready for
use!**