

Window Film **Installation Instructions**

1. Prepare the surface. Surface should be clean and free of dust.
2. Fill a pump or trigger-spray bottle with water (soapy water recommended). Generously spray water, on the window until beads of the water run down the glass. If the window becomes dry, rewet it completely before applying film. Too much water is better than not enough.
3. Remove the liner at the back of the window film. Apply the adhesive side of the film to the wet glass. Start at the top of the window, and then allow the film to gently lay down onto the glass. Work from top to bottom and use your hands to smooth the film onto the glass.
4. Wet the top of the film and remove the air bubbles by pressing firmly on the window film. Start about 2" from the top and side and squeegee from left to right, but leave the 2" perimeter area unsqueegeed. If you need to remove large air pockets, rewet the top of the film and squeegee again.
5. Trim the edges of the window film if any and then finish all the edges around the window.
6. And lastly...we would highly appreciate if you can take a moment to send us a picture of your project at EMA@newlinkz.com

Questions? – Call Us: 1 855 855 8880