



NOTES:

- A. VISIT GCPAT.COM FOR THE MOST CURRENT DETAILS AND INSTALLATION VIDEO
- B. REFER TO PRODUCT DATA SHEETS ON WEB SITE FOR FURTHER INFORMATION
- C. THE DRIP EDGE IS INSTALLED OVER THE FIRST LAYER OF GCP UNDERLAYMENT
- D. DO NOT INSTALL GCP UNDERLAYMENT OVER CEDAR SHINGLES (REFER TO TECHNICAL LETTER #15)
- E. A SECOND LAYER OF GCP UNDERLAYMENT IS INSTALLED OVER THE DRIP EDGE
- F. INSTALL GCP UNDERLAYMENT TO FORM WATER-SHEDDING LAPS
- G. REPAIR ALL HOLES LEFT FROM REMOVAL OF TOE BOARDS, ROOF JACKS, ETC.



**EAVE OPTION-2
WITH DRIP EDGE STRIPPED-IN
GRACE ICE & WATER SHIELD®**

Drawing: IWSDET-102

Scale: Not to scale

Effective Date: 01/22/18

Supersedes: 01/26/2007