

WindeeVENT

In addition to the many benefits of the Windee Vent System, it is also very easy to install. With the proper tools, the two vents can be installed in as little as 30 minutes. The system consists of two louvered vents, mounting hardware, sealant tape and a back plate that doubles as a template for cutting the opening in the garage door.

Tools List (not included)

Drill
1/4" Drill Bit
Metal Cutting Tool (dremel, shears, snips)
Wrench (10mm socket)
Level
Pencil

Parts List (included)

2 mechanical louvers
2 sets of mounting hardware
10 bolts
10 nuts
2 rolls of sealant tape
2 back plates / cutting templates

Installation Instructions

Note: Always use proper safety gear.

Note: Do not operate the garage door at any time during installation.

1. Select locations to install vents.

Note: It is recommended that vents be installed opposite of each other, ie, the top left side and bottom right side.

2. Position and level template / back plate at the install location.

Note: It is important to ensure back plate is level before cutting.

3. Mark bolt locations and trace the inside of the leveled template.

4. Cut along the traced template line.

Note: If using snips, drill a hole on traced line for a starting location.

5. Drill holes for bolts.

6. Apply sealant tape to back of vent.

Note: Remove adhesion cover on both sides before inserting bolts. Making an incision through the tape after applying to the back of the vent will help bolts punch through tape.

7. Insert all bolts through holes on the vent.

8. Insert vent and all bolts through garage door and press unit firmly to allow tape to bond with door.

Note: For maximum adhesion, the surface must be clean.

9. From inside the garage, line up back plate through bolts, attach nuts and tighten to secure vent.

10. Enjoy your new Windee Vent System.