



**1. Mount in fiberglass:** Position attachment where desired, Top/Bottom holes slits line to be mounted at a tilt. Mark Top hole with bottom opposite hole. Drill in recommend screw type (below). Mount then tighten top screw to secure in place.

**2. Mount in plastic:** As shown, you can mount here safely without penetrating the ladder's integrity, meeting OSHA standards. Follow steps above, but in the plastic area shown.

**Recommended Screw Type #6 1/2"**

