



AN **ORIGINAL** GRANITE BRACKET™ PRODUCT

THE ORIGINAL BRIDGE BRACKET



1. Mark 3"-6" from the outer edge of the cabinet for your first pocket to be cut. Then set marks for the remaining brackets every 16"-20" apart for the best counter top protection.



2. Rout or chisel a 2.5" wide by 1.0" deep pocket at each mark. This "pocket" will allow the bracket to sit flush with the top of the cabinet. Check to make sure it is flush.



3. Once the "pocket" is made in the cabinet, simply insert the bracket into place. Making sure once again that it is flush with the top of the cabinet.



4. Once your brackets are in position, simply place your countertop on top of the brackets and into place.



5. Check once again that the counter top is level. Once level, caulk around the brackets with clear silicone to hold your counter top securely.



SHOP ALL BRACKETS



SCAN FOR
MORE PRODUCTS

ORIGINALGRANITEBRACKET.COM | 888-584-1112

***BRACKET AVAILABLE
IN MULTIPLE SIZES**