



REPLACEMENT PART LIST

ENGINEERED HARDWOOD FLOORING AND COORDINATING MOLDINGS

| MODEL NAME | CARTON FLOOR MODEL NUMBER | PALLET FLOOR MODEL NUMBER | NOSING MODEL NUMBER | FLUSH REDUCER MODEL NUMBER | T-MOLDING MODEL NUMBER |
|------------|---------------------------|---------------------------|---------------------|----------------------------|------------------------|
| Steward | A30077 | A30077PL | A30077SN | A30077RD | A30077TM |
| Teaberry | A30078 | A30078PL | A30078SN | A30078RD | A30078TM |
| Stout | A30079 | A30079PL | A30079SN | A30079RD | A30079TM |
| Holland | A30080 | A30080PL | A30080SN | A30080RD | A30080TM |
| Brooke | A30081 | A30081PL | A30081SN | A30081RD | A30081TM |
| Bennett | A30082 | A30082PL | A30082SN | A30082RD | A30082TM |
| Braxton | A30083 | A30083PL | A30083SN | A30083RD | A30083TM |
| Jackson | A30084 | A30084PL | A30084SN | A30084RD | A30084TM |
| Lyon | A30085 | A30085PL | A30085SN | A30085RD | A30085TM |