

Lay Flat Hose Installation Instructions



Steps:

1. Insert 2 T-Bar Clamps onto either end of hose
2. Insert Pin Lug Female Connector into one side of hose
3. Insert Male Hose Shrank to other end of Hose
4. Tighten the 4 T-Bar Clamps to secure the pin lug connectors