

latex•ite[®] **PRO SIZE**

Crack Filler

for Asphalt Driveways & Parking Lots

Asfalto calzadas y estacionamientos

USES

- To fill cracks in asphalt driveways
- Expansion Joints

DIRECTIONS

1. Clean cracks thoroughly.
2. Use for cracks up to 1/2" wide.
3. Apply when temperature is above 55°F & rain is not imminent for at least 24 hours.
4. Cracks over 1/2" deep should be filled with solid material to 3/8" from surface before caulking.
5. Cut nozzle at 45° angle to desired opening size. Puncture seal with caulk gun device or pointed object such as a nail. Apply directly into crack using caulk gun.
6. Do not overfill.
7. Allow to fully cure prior to sealing.

INSTRUCCIONES

1. Limpie las grietas minuciosamente.
2. Utilice el producto en grietas de hasta 1/2" de ancho.
3. Aplique el producto con una temperatura superior a los 55° F y cuando no se haya pronosticado una lluvia inminente antes de las 24 horas de su aplicación.
4. Las grietas de más de 1/2" de profundidad deberán rellenarse con material sólido hasta 3/8" de la superficie antes del retacado.
5. Corte la boquilla a un ángulo de 45° al tamaño de abertura deseado. Punción selle con un dispositivo de pistola de calafateo o un objeto puntiagudo como un clavo. Aplicar directamente en la grieta con pistola de calafateo.
6. No rellene en exceso.
7. Permita que se seque totalmente antes de sellar.

latex•ite[®] is a trademark of:

Dalton Enterprises, Inc.

Cheshire, CT

www.latextite.com