

# SPLASHBACK TILE

## Use & Care Manual

### **SUBSTRATE**

Tile must be installed over a suitable substrate to insure a proper installation. Tile should be installed over a clean, sound, and flat surface, free of contaminants including curing compounds. Substrate should be free of cracks. If used in a wet area you must waterproof. Tile must be sealed.

### **INSTALLATION**

- To avoid affecting the color of the tile, White modified thin-set is recommended for all installations.
- Apply as much adhesive as can be covered within 10-15 minutes.
- Grout joint should be a minimum of 1/16" and not butt set.
- The trowel size you can use is a 9" Trowel - 1/16" square notch.

### **GROUTING**

- Use Non-Sanded grout
- Grout joints should be packed full and free of voids and pits.
- Clean excess grout as the work progresses before it has hardened completely.
- Acids should never be used for cleaning grout haze.
- Use a damp sponge for the final cleaning and to smooth out the grout joints.
- It is recommended to use grout release, then grout the tile, then use a sealant to the tile such as our MP90
- **Highly recommended to purchase the Glass & Stone Installation/Maintenance Kit –**

### **CUTTING**

The recommended cutting method is to use a wet saw with a diamond blade that is specifically for cutting glass. Edges can be sanded smooth after cutting.