

Hammered Dome Cap Nut

Ornamental Hardware

Item #: 56622



Replacement Parts

Kit Includes:

10 Hammered Dome Cap Nuts (a)



- Decorative hardware conceals lag screws
- Lag Screws Sold Separately

**Ornamental
Wood Ties**

OZCO

Hammered Dome Cap Nut Item #: 56622

Ornamental Hardware - Installation Guide



Steps:

1. Remove threaded covers from all Dome Cap Nuts
2. Insert Lag Bolts into Cap Nut
3. OWT Lag Bolts require a 3/8" Hex Bit
4. Replace Threaded Covers do not over tighten
5. HINT: Use tread lock on Threaded Covers in accessible areas

Use and Care: This hardware may not be suitable for every situation or installation application. A design professional should be consulted to ensure the specific installation application meets local building code requirements.

If hardware becomes dirty clean with soap and water. Avoid abrasions to surface and touch up any scrapes with paint. Rinse with fresh water if hardware comes in contact with ice salt or salt water.