



INSTALLATION:

1. Cut to desired length.
2. **IMPORTANT:** When hammering down fasteners, protect nail heads from chipping by placing clear tape over the heads. Replace tape for each screw nail installed.
3. Wood floors: Use provided screw nails.
Concrete floors: Install with provided screws & wood pegs (sold separately).
4. Position shorter leg on carpet.

