

Universal Flange Is Ready To Install

Select a decorative matching or contrasting Décor Series Trim Ring for a custom, enhanced finished appearance.

Instructions:

1. The log lighter gas valve must be in the **OFF** position.
2. Remove the existing valve flange by unscrewing in a counter-clockwise direction.
3. Add an optional decorative flange trim ring by slipping it over the new Universal Flange shank before completing the final installation.
4. Install the new flange using the threaded bushing if the thread size matches the original flange. If it does not match, remove the bushing prior to completing the final installation.
5. Loosen the set screw using the set screw wrench provided. Screw the flange and trim ring assembly onto the gas valve to the desired length and retighten the set screw.

Purchase of a matching or contrasting decorative universal gas valve key (3" or 8" as needed) can complete the final desired custom look for your home.

(Spanish Instructions On Reverse)
Instrucciones en español al reverso

Canterbury
Enterprises

Made In Indonesia
Hecho en Indonesia

U.S. Patent No. 7,296,589

www.blueflamestore.com
800—321—6566

Universal Flange Is Ready To Install

Select a decorative matching or contrasting Décor Series Trim Ring for a custom, enhanced finished appearance.

Instructions:

1. The log lighter gas valve must be in the **OFF** position.
2. Remove the existing valve flange by unscrewing in a counter-clockwise direction.
3. Add an optional decorative flange trim ring by slipping it over the new Universal Flange shank before completing the final installation.
4. Install the new flange using the threaded bushing if the thread size matches the original flange. If it does not match, remove the bushing prior to completing the final installation.
5. Loosen the set screw using the set screw wrench provided. Screw the flange and trim ring assembly onto the gas valve to the desired length and retighten the set screw.

Purchase of a matching or contrasting decorative universal gas valve key (3" or 8" as needed) can complete the final desired custom look for your home.

(Spanish Instructions On Reverse)
Instrucciones en español al reverso

Canterbury
Enterprises

Made In Indonesia
Hecho en Indonesia

U.S. Patent No. 7,296,589

www.blueflamestore.com
800—321—6566

Universal Flange Is Ready To Install

Select a decorative matching or contrasting Décor Series Trim Ring for a custom, enhanced finished appearance.

Instructions:

1. The log lighter gas valve must be in the **OFF** position.
2. Remove the existing valve flange by unscrewing in a counter-clockwise direction.
3. Add an optional decorative flange trim ring by slipping it over the new Universal Flange shank before completing the final installation.
4. Install the new flange using the threaded bushing if the thread size matches the original flange. If it does not match, remove the bushing prior to completing the final installation.
5. Loosen the set screw using the set screw wrench provided. Screw the flange and trim ring assembly onto the gas valve to the desired length and retighten the set screw.

Purchase of a matching or contrasting decorative universal gas valve key (3" or 8" as needed) can complete the final desired custom look for your home.

(Spanish Instructions On Reverse)
Instrucciones en español al reverso

Canterbury
Enterprises

Made In Indonesia
Hecho en Indonesia

U.S. Patent No. 7,296,589

www.blueflamestore.com
800—321—6566

Universal Flange Is Ready To Install

Select a decorative matching or contrasting Décor Series Trim Ring for a custom, enhanced finished appearance.

Instructions:

1. The log lighter gas valve must be in the **OFF** position.
2. Remove the existing valve flange by unscrewing in a counter-clockwise direction.
3. Add an optional decorative flange trim ring by slipping it over the new Universal Flange shank before completing the final installation.
4. Install the new flange using the threaded bushing if the thread size matches the original flange. If it does not match, remove the bushing prior to completing the final installation.
5. Loosen the set screw using the set screw wrench provided. Screw the flange and trim ring assembly onto the gas valve to the desired length and retighten the set screw.

Purchase of a matching or contrasting decorative universal gas valve key (3" or 8" as needed) can complete the final desired custom look for your home.

(Spanish Instructions On Reverse)
Instrucciones en español al reverso

Canterbury
Enterprises

Made In Indonesia
Hecho en Indonesia

U.S. Patent No. 7,296,589

www.blueflamestore.com
800—321—6566

El Borde Universal Esta Listo Para Instalarse

Seleccione la argolla a tono o de contraste de las series Décor para una apariencia mejor y a su gusto.

Instrucciones:

1. La válvula del ducto alimentador debe estar en la posición de apagado.
2. Remueva el borde actual desatornillandolo en sentido en el que giran las manecillas del reloj.
3. Puede agregar una argolla decorativa al borde de madera revalandolo sobre el nuevo mango del borde universal antes de completar la instalación.
4. Instale el nuevo borde usando.
5. Afloje el set de tornillos usando la llave provista. Atornille el borde y la argolla de montaje sobre la válvula de gas a la longitud deseada y atornillelo nuevamente.

La compra de la llave de la válvula de gas decorativa (3" ó 8" depende de como sea necesario) puede completar el toque final de su gusto a su hogar.

Empresas
Canterbury

Hecho en Indonesia
U.S. Patent No. 7,296,589



El Borde Universal Esta Listo Para Instalarse

Seleccione la argolla a tono o de contraste de las series Décor para una apariencia mejor y a su gusto.

Instrucciones:

1. La válvula del ducto alimentador debe estar en la posición de apagado.
2. Remueva el borde actual desatornillandolo en sentido en el que giran las manecillas del reloj.
3. Puede agregar una argolla decorativa al borde de madera revalandolo sobre el nuevo mango del borde universal antes de completar la instalación.
4. Instale el nuevo borde usando.
5. Afloje el set de tornillos usando la llave provista. Atornille el borde y la argolla de montaje sobre la válvula de gas a la longitud deseada y atornillelo nuevamente.

La compra de la llave de la válvula de gas decorativa (3" ó 8" depende de como sea necesario) puede completar el toque final de su gusto a su hogar.

Empresas
Canterbury

Hecho en Indonesia
U.S. Patent No. 7,296,589



El Borde Universal Esta Listo Para Instalarse

Seleccione la argolla a tono o de contraste de las series Décor para una apariencia mejor y a su gusto.

Instrucciones:

1. La válvula del ducto alimentador debe estar en la posición de apagado.
2. Remueva el borde actual desatornillandolo en sentido en el que giran las manecillas del reloj.
3. Puede agregar una argolla decorativa al borde de madera revalandolo sobre el nuevo mango del borde universal antes de completar la instalación.
4. Instale el nuevo borde usando.
5. Afloje el set de tornillos usando la llave provista. Atornille el borde y la argolla de montaje sobre la válvula de gas a la longitud deseada y atornillelo nuevamente.

La compra de la llave de la válvula de gas decorativa (3" ó 8" depende de como sea necesario) puede completar el toque final de su gusto a su hogar.

Empresas
Canterbury

Hecho en Indonesia
U.S. Patent No. 7,296,589



El Borde Universal Esta Listo Para Instalarse

Seleccione la argolla a tono o de contraste de las series Décor para una apariencia mejor y a su gusto.

Instrucciones:

1. La válvula del ducto alimentador debe estar en la posición de apagado.
2. Remueva el borde actual desatornillandolo en sentido en el que giran las manecillas del reloj.
3. Puede agregar una argolla decorativa al borde de madera revalandolo sobre el nuevo mango del borde universal antes de completar la instalación.
4. Instale el nuevo borde usando.
5. Afloje el set de tornillos usando la llave provista. Atornille el borde y la argolla de montaje sobre la válvula de gas a la longitud deseada y atornillelo nuevamente.

La compra de la llave de la válvula de gas decorativa (3" ó 8" depende de como sea necesario) puede completar el toque final de su gusto a su hogar.

Empresas
Canterbury

Hecho en Indonesia
U.S. Patent No. 7,296,589

