

Installation Guide for Over-the-Toilet Storage Unit

Important Precautions Before Installation

1. Please confirm that all parts are complete and undamaged before starting installation. Refer to the parts list to check: thick wood panels, sturdy metal frame, storage basket, removable hooks, toilet paper holder, metal X-shaped crossbar, wall fixing nails, non-slip feet, and mounting hardware (screws, nuts, etc.).
2. Choose a flat and stable area above the toilet for installation. Ensure the installation position is away from water sources as much as possible to avoid dampness affecting the product's service life.
3. Prepare necessary tools in advance: a Phillips screwdriver, a level (to ensure the unit is horizontal), and a drill (for wall fixing, if needed). It is recommended to have two people cooperate during installation to avoid falling of parts and ensure safety.
4. Do not overload the shelves during or after installation. Follow the product's load-bearing requirements for each shelf to prevent structural damage.

Step-by-Step Installation Instructions

Step 1: Assemble the Basic Metal Frame

First, take out the metal frame components. Align the vertical metal poles with the horizontal connecting poles according to the marked positions on the parts. Insert the screws into the pre-drilled holes and tighten them with a Phillips screwdriver. Do not fully tighten the screws temporarily; leave a small gap for subsequent adjustment. After assembling the four-sided frame, place it on a flat surface and use a level to check if it is horizontal and vertical. Adjust the position of the poles if necessary, then fully tighten all screws to ensure the frame is stable.

Step 2: Install the Metal X-Shaped Crossbar

Take the metal X-shaped crossbar and align its connecting ends with the pre-set mounting points on the inner side of the metal frame. Fix the crossbar to the frame using the matching screws and nuts. Tighten the fasteners firmly to enhance the overall stability of the frame and prevent shaking during use.

Step 3: Install Non-Slip Feet

Take the non-slip feet and screw them into the pre-drilled holes at the bottom of the metal frame one by one. Ensure each non-slip foot is fully tightened to make the unit stand stably on the ground. The non-slip feet can not only protect the floor from scratches but also reduce the movement of the unit during use.

Step 4: Install Wooden Shelves

Take out the thick wood panels (shelves) and place them on the pre-set supports inside the metal frame. Adjust the position of the shelves according to your storage needs: if you need to place taller bottles or bulky containers, adjust the distance between the shelves by moving the supports up and down. After confirming the position, use the small screws provided to fix the shelves to the frame (if equipped) to prevent the shelves from sliding. Repeat this step to install all four tiers of shelves in sequence.

Step 5: Install Auxiliary Components

1. **Storage Basket:** Align the mounting hooks on the back of the storage basket with the pre-set hanging points on the frame. Hang the basket firmly on the frame to ensure it is stable and will not fall. The anti-fall design of the basket will keep items secure.

2. **Removable Hooks:** Tear off the protective film on the back of the removable hooks (if they are adhesive-type) and stick them to the desired position on the frame. Press firmly for 30 seconds to ensure they are firmly attached. If using screw-mounted hooks, drill small holes at the marked positions, then fix the hooks with screws.

3. **Toilet Paper Holder:** Align the toilet paper holder with the pre-drilled holes on the side of the frame. Insert the screws and tighten them with a screwdriver to fix the holder firmly. Ensure the holder is level so that the toilet paper can rotate smoothly.

Step 6: Fix the Unit to the Wall (Optional but Recommended)

For enhanced stability, especially to prevent the unit from tipping over, it is recommended to fix it to the wall. Use a drill to drill holes at the marked positions on the wall (matching the position of the wall fixing nails). Insert the expansion tubes into the holes (if the wall is concrete or brick), then align the mounting points on the top of the metal frame with the wall holes. Drive the wall fixing nails into the expansion tubes and tighten them to fix the unit firmly to the wall.

Post-Installation Check

1. After completing all installation steps, gently shake the storage unit to check if it is stable and has no obvious shaking or loose parts. If any looseness is found, re-tighten the corresponding screws immediately.

2. Check whether all auxiliary components (storage basket, hooks, toilet paper holder) are firmly installed and can be used normally.

3. Confirm that the wooden shelves are level and stable, and there is no risk of sliding or falling.

Tips for Use and Maintenance

1. Do not place heavy items exceeding the load-bearing limit on the shelves to avoid damaging the frame or shelves.
2. When cleaning the unit, use a dry or slightly damp cloth to wipe; do not use corrosive cleaning agents to avoid damaging the rustic brown finish and metal frame.
3. If the unit is used in a humid environment (such as a bathroom), regularly check the tightness of the screws and the condition of the wood panels to prevent dampness and corrosion.
4. When adjusting the position of the wooden shelves, first remove the items on the shelves to avoid injury caused by falling items.