



Start at the eave by positioning a line of butyl tape on the roof edge. Remove the release paper on the tape and gently embed the foam closure strip.

Install metal roofing panels, fastening through the closure strip with the appropriate amount of fasteners as set out in local building codes.

When you get to the ridge, apply another line of butyl tape to the roof panel. Remove the release paper, then embed the closure strip, just before installing the ridge cap.

Corrugated foam closure strips do not have separate inside and outside closure strips as most metal roofing panels do. Simply flip the closure strip over to turn an inside closure strip to an outside closure strip.



CAUTION!

Working above grade is inherently dangerous, be sure that proper fall protection measures are in place. When working with power tools and sheet metal, gloves and eye protection are absolutely required.