



7 WAY BLADE TO 4 WAY FLAT

INSTALLATION INSTRUCTIONS
INSTRUCCIONES DE INSTALACION)
CONSIGNES D' INSTALLATION

READ ALL WARNINGS AND INSTRUCTIONS BEFORE INSTALLATION

WARNING: CONSULT VEHICLE AND TRAILER OWNER'S MANUAL BEFORE INSTALLATION.

INSTALLATION INSTRUCTIONS

1. PLUG THE ADAPTER INTO THE 7-WAY FLAT PIN CONNECTOR ON THE TOWING VEHICLE.
2. PLUG THE 5-WAY FLAT CONNECTOR FROM THE TRAILER INTO TO THE ADAPTER.
3. TEST TRAILER FUNCTIONS.

LEA TODAS LAS ADVERTENCIAS E INSTRUCCIONES ANTES DE LA INSTALACIÓN

ADVERTENCIA: CONSULTE EL MANUAL DEL PROPIETARIO DEL VEHÍCULO Y DEL REMOLQUE ANTES DE LA INSTALACIÓN.

INSTRUCCIONES DE INSTALACIÓN

1. ENCHUFE EL ADAPTADOR EN EL CONECTOR PLANO DE 7 VÍAS CON CLAVIJA EN EL VEHÍCULO DE ARRASTRE.
2. ENCHUFE EL CONECTOR PLANO DE 5 VÍAS DEL REMOLQUE EN EL ADAPTADOR.
3. PRUEBE LAS FUNCIONES DEL REMOLQUE.

LISEZ TOUS LES AVERTISSEMENTS ET TOUTES LES INSTRUCTIONS AVANT L'INSTALLATION.

AVERTISSEMENT: CONSULTEZ LE MANUEL DU PROPRIÉTAIRE DU VÉHICULE ET DE LA REMORQUE AVANT L'INSTALLATION.

INSTRUCTIONS POUR L'INSTALLATION

1. BRANCHEZ L'ADAPTATEUR DANS LE CONNECTEUR À BROCHES PLATES À 7 VOIES DU VÉHICULE REMORQUEUR.
2. BRANCHEZ LE CONNECTEUR À BROCHES PLATES À 5 VOIES DE LA REMORQUE DANS L'ADAPTATEUR.
3. VÉRIFIEZ LES FONCTIONS DE LA REMORQUE.

IF YOU EXPERIENCE ANY PROBLEMS WITH YOUR TOWSMART PRODUCT DO NOT RETURN THE UNIT TO THE RETAILER FROM WHICH IT WAS PURCHASED. INSTEAD, PLEASE CALL 1-844-295-9215 FOR ASSISTANCE WITH ANY PROBLEMS. WARRANTY INFORMATION IS AVAILABLE UPON REQUEST AND CAN BE FOUND ONLINE AT WWW.TOWSMART.COM.



Winston Products Company
towsmart.com
WINSTON PRODUCTS, LLC.
30339 Diamond Parkway
Cleveland, OH 44139