

⚠ Before purchasing, please check that this SmartBidet will fit your toilet.



1. Measure the distance between the center of the toilet bolt holes. It should be between 5.5 in. to 10 in.



2. Measure the distance from the center of the toilet bolt holes to the toilet tank. The toilet will need a minimum of 1.6 in. of clearance.



3. Measure the distance from the toilet bolt holes to the front of the toilet 16.9 in. to 18.5 in.:



SB-2600 Seat Dimensions

Fits both Elongated and Round toilets but may have a slight overhang for certain round toilets.

