

## INSTALLATION GUIDE

Product: 16 Pack 6 Inch LED Recessed Ceiling Light, Dimmable, 6000K Clear White, 1050LM 12W  
120V, High Brightness Canless Wafer Downlight

-----

### Tools Needed

- Measuring tape
- Pencil
- Hole saw or drywall cutter
- Screwdriver
- Wire connector (included)

### Step-by-Step Installation

#### 1. Preparation

- Turn off the power at the circuit breaker or fuse box before installation.
- Confirm the ceiling material and select the installation location.
- Ensure at least 2 inches of ceiling space is available.

#### 2. Cut the Hole

- Use the provided cut-out template to mark the hole on the ceiling.
- Cut along the marked circle with a hole saw or drywall cutter.

#### 3. Wiring the Junction Box

- Open the junction box cover.

- Connect the house wires to the corresponding light wires:
  - Black -> Live (L)
  - White -> Neutral (N)
  - Green -> Ground (G)
- Use the included wire connectors to secure all connections.
- Close the junction box cover securely.

#### 4. Connect the Light

- Plug the light connector into the junction box port.
- Check all connections to ensure they are secure.

#### 5. Mount the Light

- Squeeze the spring clips on both sides of the light and insert them into the ceiling hole.
- Release the clips, allowing them to hold the light firmly against the ceiling.

#### 6. Power On and Test

- Turn on the power and test the light to ensure proper installation.
- Adjust dimming as needed (compatible with most standard dimmers).

#### Safety Notes:

- Suitable for damp locations.
- Do not install near insulation without proper clearance.
- Avoid contact with water or flammable materials.