

Schluter®-JOLLY



FINISHING AND EDGE PROTECTION FOR WALLS AND COUNTERTOPS

EDGE-PROTECTING PROFILE

Installation Instructions

1. Select Schluter®-JOLLY according to tile thickness.
2. Using a notched trowel, apply thin-set mortar to the area where profile is to be placed. If Schluter®-JOLLY is to be used at outside wall corners, finish tiling one wall first; then trowel thin-set mortar over the corner area of the second wall.
3. Press the perforated anchoring leg of profile into the mortar and align.
4. Trowel additional thin-set mortar over the perforated anchoring leg to ensure full coverage and support of the tile edges.
5. Solidly embed the tiles so that the tiled surface is flush with the top of the profile; the profile should not be higher than the tiled surface, but rather up to approx. 1/32" (1 mm) lower.
6. Set the tile to the integrated joint spacer, which ensures a uniform joint of 1/16" - 1/8" (1.5 - 3 mm).



7. Fill the joint completely with grout or setting material.
8. Work with materials and tools that will not scratch or damage sensitive surfaces. Setting materials must be removed immediately, especially from aluminum.

