



## HOW TO INSTALL METAL SPEEDTILES

1. Make sure the wall where you want to install the SpeedTiles is **CLEAN** and **SMOOTH**.
2. To get the best possible results, spread the tiles in front of you and arrange them to find the most pleasing layout.
3. **ADHESION PRO TIP:** Fill an empty spray bottle with water (500ml-750ml) and add 1 to 2 teaspoon(s) of soft dishwashing soap.
4. Find where the counter is the highest and **draw a level line** over it. This is your guide to install the first row of tiles.
5. When installing the tiles, remove the backing paper Inoxia from the back side of the tile (pre-cut if required).  
**Spray a SMALL amount** of the water-detergent mix onto the adhesive and spread it with your hand **over the whole surface**. Adding this liquid delays bonding and allows you to perfectly adjust the tile on the wall.
6. Once the tiles are positioned, use a grout float to press the tiles into place (or a perfectly smooth and clean plank, as well as a rubber hammer to gently tap the whole surface).
7. For a pro finish, you can use a silicone of your choosing.

### HOW TO CUT SPEEDTILES?

Use a table saw, miter saw, large utility knife, wood chise, etc.





## CÓMO INSTALAR SPEEDTILES DE METAL

1. Asegúrese de que la pared donde instalará los mosaicos SpeedTiles esté **LIMPIA** y **LISA**.
2. Para obtener los mejores resultados posibles, extienda los mosaicos y seleccione el patrón correcto de instalación para conseguir el mejor resultado visual.
3. Tome una botella vacía (500 ml – 750 ml), llénela de agua y agregue de 1 a 2 cucharaditas de jabón suave para vajillas.
4. Encuentre el lugar donde el mostrador sea más alto y trace una línea desde ese punto. Esta línea le servirá de guía para la instalación de la primera línea de azulejos.
5. Durante la instalación, remueva el papel protector Inoxia detrás del azulejo (precortado si es necesario).  
Aplique **UN POCO** de agua jabonosa en el adhesivo y espárzala con la mano por toda la superficie. Este líquido sirve para retrasar la adhesión y le permite ajustar perfectamente el azulejo en la pared.
6. Cuando los mosaicos estén bien instalados, utilice una llana para ejercer presión sobre ellos o use un tablón perfectamente liso y limpio junto con un martillo de caucho para martillar suavemente por toda la superficie.
7. Para un acabado elegante, puede usar una silicona de su agrado.

### CÓMO CORTAR LOS SPEEDTILES

Sierra de mesa, sierra ingletadora, cortador, cincel de madera.

