

## Vinyl Wainscot/Planking Instructions



Install and level matching base board.

Apply bead of paneling adhesive to the back of trim

Nail trim into studs 16 inch on-center



Cut plank to measured height.

Apply bead(s) of paneling adhesive to the back of panel.

Stick panel at wall placement into base groove, neatly place panel groove over adjacent panel's tongue.

Level panel to ensure vertical.



Cap and level with matching chair rail.

Apply bead of paneling adhesive to the back of trim

Stick trim on top of panels, with groove for panels facing down

Level trim to ensure horizontal

Nail trim into studs 16 inch on-center

Apply bead of caulk along top, inner edge of trim

**MAINTENANCE:** Wipe with Damp cloth. Most household cleaners will not affect the finish; it is recommended to test cleaners in small unseen areas prior to using on entire surface. If painted, follow the paint manufacturer's instructions for cleaning.

**Complete instructions are on back side of package labels.**