

Installation Instructions

Tools:

- Tape measure & Pencil
- Paint, brush & roller
- Level
- Power or Table Saw
- Jig Saw or Coping Saw
- Brad Nailer/Hammer
- Nails
- Eye goggles (*must be worn when using any power or hand tools*)



Step 1: Lumber Layout

- Organize and lay out your Barnline Vintage Lumber on a flat surface, such as a floor or large table. This should resemble the way you would like them displayed on your surface. Many options are possible such as vertical, horizontal, diagonal or herringbone. Pick the planks so each row is the same width but vary the order from row to row and piece length to compliment the natural variation of the vintage wood.



Step 2: Surface Prep

- Paint your surface a dark color to conceal any holes in your lumber.
- If fastening to a wall, mark your studs after painting, ensuring fasteners penetrate into studs.
- Remove any outlet or light switch covers. Measure and mark where the covers will be on the lumber. Use a jig saw or coping saw to cut out these areas so you can easily re-apply covers after installation.



Step 3: Install

- Install your first row of lumber. This can be done in a horizontal, vertical or diagonal (angled) fashion. If you are applying in a horizontal orientation, use a level. If you are applying to the surface in a diagonal (angled) orientation, place your first row at the angle you prefer.
- Hold in place, fasten your lumber with nails. If placing on a wall, use the marked studs as a reference of where to fasten.
- Optional: If you choose to use wood glue or another form of adhesive, apply directly to back side of your lumber before placing and securing pieces to your surface.

For more installation tips, go to www.homedepot.com or www.realdealbarnwood.com to watch an installation video.