

MODEL AC-207

TOOLS NEEDED / SE REQUIERE HERRAMIENTA



Foam Air Conditioner Side Insulation Panels

Paneles de Aislamiento Laterales Para Aire Acondicionado

Installation

Instalación

- 1** Remove the existing side panels, leaving the frame.
- 2** Measure the height of the air conditioner.
- 3** Cut the foam panel and the plastic channel to the proper height.
- 4** Slide the uncovered edge of the panels into the frame.
- 5** Remove the protective strip from the plastic channel and press it firmly against the side of the air conditioner.
- 6** For additional insulation, install the panels on top of the existing panels.

- 1** Quite los paneles existentes de ambos lados, dejando el marco.
- 2** Mida la altura del aparato de aire acondicionado.
- 3** Corte el panel de espuma y el canal plástico a la medida.
- 4** Deslice la orilla lisa en el marco.
- 5** Retire la tira protectora del canal plástico y presiónelo firmemente al lado del aparato de aire acondicionado.
- 6** Para más aislamiento, instale los paneles nuevos encima de los paneles existentes.

MODEL AC-207

