

# Delta Shower Door Measurement Guide

Choosing the right Shower Door is as easy as 1-2-3. But before you customize your dream door, you need to make sure you have the correct measurements:

**Identify Vertical and Horizontal Openings with Threshold Depth** 

Height (A), Widths (B), and Depth (C). Widths (B) measurements are often not the same so doors can be adjusted up to 3/8"

#### A) Vertical Opening

Measure from the top of the shower or bathtub threshold up to the top of the acrylic (or tile) surround wall

#### **B) Horizontal Opening**

Measure width of opening at the top and the bottom of the enclosure.

#### C) Threshold/Sill

Measure the depth from front to back (edge to edge) of the shower or bathtub threshold.

#### **Available Sizes:**

#### • 27-30" Pivot Shower

- Fits openings 27" minimum 30" maximum
- Finished Door Height: 64-3/4"
- Minimum Required Clearance Height for Installation: 66-3/4"
- Threshold/Sill Depth Requirement for Installation: 1-1/2"
- This door does not have a stud placement requirement

#### • 30-33" Pivot Shower

- Fits openings 30" minimum 33" maximum
- Finished Door Height: 64-3/4"
- Minimum Required Clearance Height for Installation: 66-3/4"
- Threshold/Sill Depth Requirement for Installation: 1-1/2"
- This door does not have a stud placement requirement

#### • 33-36" Pivot Shower

- Fits openings 33" minimum 36" maximum
- Finished Door Height: 64-3/4"
- Minimum Required Clearance Height for Installation: 66-3/4"
- Threshold/Sill Depth Requirement for Installation: 1-1/2"
- This door does not have a stud placement requirement

### RECORD DIMENSIONS BELOW

	Opening
Height (A):	
Width of widest point (B):	
Width at narrowest point (B):	

## Need Additional Assistance with Delta Shower Doors?

Call us at 1.800.964.4850
Visit us at www.deltashowerdoors.com
Email us at customersolutions@deltashowerdoors.com

# ylic A

**Pivoting Shower Doors** 

#### \*\*Disclaimers

- For ceramic tile application, use the top of the tile for the maximum door height.
- In older homes the opening at the top is often wider than the bottom due to an out-of-plumb condition.
- NOTE: All Delta Shower Doors are designed to accommodate out-of-plumb conditions totaling 3/8".