

INSTRUCTION GUIDE

TOILET FLANGE

Oatey

1 Cut the pipe to the desired height.

2 Dry fit flange into the pipe to check for interference.

3 Apply approved Oatey primer using approved application methods to the flange and the drainpipe.

4 Apply approved Oatey cement using approved application methods to the flange and drainpipe.

5 Push the flange down onto the pipe until it is setting flush with or on top of the finished floor.

6 Secure the flange in place using approved screws and possibly anchors for your application. Screws should pass through the finished floor and be secured into the subfloor.

7 Find the center of the flange and install the Johni-bolts.

