



## INSTALLATION INSTRUCTIONS

- Remove old floor, and underlayment for any that are unsound or deteriorated
  - **Any previous rigid floor can be left in place if it is sound and firmly adhered to the substrate**
- *Do not attempt to remove asbestos tiles yourself, have a professional do this who is licensed*
- Clean and sweep the concrete floor
- Inspect for cracks in the concrete
- For cracks larger than 1/16", fill with Quikrete concrete repair (As per their instructions)
- Check the level of the floor with a draw string, it should not exceed a 3mm difference over 3m, or 1/8" over 10'.
- If required, level the floor with self leveling concrete compound or Pre-Mixed Floor Patch

### Laminate and Engineered Hardwood

- Lay DMX 1-Step™ with the dimples facing down
- If perimeter walls are finished to drywall, leave a ¼" gap between the 1-Step™ and foundation
- If perimeter walls are unfinished, take 1-Step™ to foundation wall and seal with foam
- Tape the seams of 1-Step™ (tape along the length of the seam first, then tape across)
- Lay down your laminate (6 mm minimum for application directly on top of 1-Step.). The thicker the laminate the firmer the floor will seem. It is recommended that the laminate flooring be laid perpendicular to the joints in the 1-Step™, where feasible
- Follow the laminate manufacturers installation instructions for proper fit of the floor
- Allow ¼" clearance between drywall and laminate
- Leave baseboards up off finished floor a minimum of 1/16" to 1/8" for air circulation



## INSTRUCCIONES DE INSTALACIÓN

- Retire el piso anterior y toda base no sólida o deteriorada.  
**Es posible dejar todo piso rígido anterior en su lugar si es sólido y está firmemente adherido al sustrato.**
- *No intente retirar mosaicos de asbesto usted mismo; contrate a un profesional con licencia para que lleve a cabo esta tarea.*
- Limpie y barra el piso de hormigón.
- Inspeccione para asegurarse de que no haya grietas en el hormigón.
- Si las grietas miden más de 1/16", rellene con hormigón de reparación Quikrete (según las instrucciones del fabricante).
- Verifique la nivelación del piso con un cordel; no debe exceder una diferencia de 3 mm en un radio de 3 m, o bien 1/8" en un radio de 10'.
- Si es necesario, nivele el piso con el compuesto de nivelación de hormigón o Pre-Mixed Floor Patch.

### Madera maciza laminada y diseñada

- Disponga DMX 1-Step™ con los hoyuelos hacia abajo.
- Si las paredes del perímetro tienen acabado de mampostería, deje un espacio de ¼" entre el 1-Step™ y los cimientos.
- Si las paredes del perímetro no tienen acabado, coloque el 1-Step™ en la pared de cemento y selle con espuma.
- Coloque cinta en las juntas de 1-Step™ (a lo largo de la junta y, a continuación, en sentido perpendicular).
- Extienda el laminado (6 mm como mínimo para aplicar directamente sobre 1-Step.). Si el laminado es más grueso, más firme parecerá el piso. Recomendamos instalar el piso laminado en forma perpendicular a las juntas del 1-Step™, si es factible.
- Siga las instrucciones de instalación del fabricante del piso laminado para lograr un calce adecuado.
- Deje un espacio de ¼" entre la pared de mampostería y el laminado.
- El zócalo debe sobresalir del piso terminado un mínimo de 1/16" a 1/8" para permitir la circulación de aire.