

Installation Guide

Package Contents Check

Before installation, confirm all components are intact: 1 touchless foaming soap dispenser, 1 USB charging cable, and wall-mount adhesive accessories (if included). Ensure the dispenser's surface and anti-slip pad (bottom) are free of dust or damage.

Option 1: Countertop Installation (No Tools Required)

1. Choose a flat, dry, and stable surface (kitchen countertop, bathroom vanity, etc.) away from water splashes or direct sunlight. 2. Confirm the anti-slip pad is firmly attached to the bottom of the dispenser—this prevents slipping and protects the desktop from scratches. 3. Place the dispenser gently on the selected surface, adjust to a desired position, and press lightly to ensure stability. 4. The countertop installation is complete. Proceed to charge and refill soap before use.

Option 2: Wall-Mounted Installation (Adhesive, No Drilling)

1. Select a suitable wall location: smooth, non-porous, dry, and free of oil or dust (tile, glass, or polished wood surfaces are recommended; avoid rough or porous walls). 2. Clean the wall surface with a dry cloth to remove any dirt, oil, or moisture—this ensures strong adhesion. 3. Peel off the protective film from the adhesive pad (attached to the back of the dispenser or included separately). 4. Align the dispenser with the marked wall position, press firmly against the wall for 30 seconds to expel air, ensuring full contact between the adhesive pad and the wall. 5. Allow the adhesive to set for 24 hours before use—this maximizes adhesion strength and prevents falling. 6. To remove the dispenser later, gently peel it off the wall. Do not pull forcefully to avoid damaging the wall surface.

Post-Installation Notes

1. After installation, ensure the dispenser is stable and does not wobble. 2. Keep the dispenser away from high temperatures, open flames, and sharp objects. 3. For wall-mounted use, do not hang heavy items on the dispenser to avoid adhesive failure. 4. If the wall surface is uneven or porous, use additional mounting hardware (not included) for reinforcement. 5. Before formal use, fully charge the dispenser and refill with appropriate soap (foam soap recommended or diluted liquid soap at 1:3 ratio).