

INSTALLATION

Tools Needed:

- Power drill with Phillips head screw driver.
- 2 stainless steel screws (*Included with Nature Bracket*)

1. Remove old supportive bracket (*if there is one*) from mailbox.
2. Place new decorative Nature Bracket in position.
3. Drive screws into bracket and onto post until secure.

