



NO-DIG EDGING KIT EASY TO INSTALL

INST-VNDIG-RV2

INSTALLATION INSTRUCTIONS



- 1** Clear the installation area of all grass, loose soil, mulch, and debris. Place edging on the cleared surface with anchoring tabs facing the planting bed.



- 2** Use a rubber mallet to pound anchoring spikes through tabs to secure the edging. Pull the edging tight between spikes.



- 3** Backfill to the top of the edging with mulch, rock, or other ground cover. Assure tabs are completely covered with a thick layer of bedding material.

HELPFUL TIPS & INFORMATION

Preparation:

Soil must be solid and level. Assure there is no debris between the landscape edging tab and the dirt below. Compact the cleared soil prior to installation to reduce spike movement from shifting ground and frost heave.

Weed fabric can minimize the spread of invasive weeds and grass. If desired, install fabric according to product directions. Then, place the landscape edging over the fabric and begin to pound anchoring spikes through the edging tabs and weed fabric.

Before installation, it is important to let the edging relax in the sun to allow for thermal expansion. Installing the edging when expanded and pulling tightly can reduce undesirable waves in straight installations.

Installation:

Certain conditions and landscape designs will require additional spikes, which are sold separately in stores and online.

Use a rubber mallet to pound spikes into the ground. Pound spikes only to the top of the edging tab. Too much tension on tabs can result in wavy edging.

To connect edging ends, overlap the final tab on each end and pound spike through both holes.

Cutting the Edging:

Cut edging at the midpoint between the anchoring tabs using hand snips or a fine tooth saw.

