Railing Installation hardware:

Self-Tapping Screws
Wall Anchor Screws (masonry anchors sold separately)
Wall Brackets

Installation Tips:

1) Determine your preferred railing height (usually around 36" Check your local code) locate the studs in your wall (if interior). Space the two wall brackets at the proper stud distance on the underside of the railing.

2) While securely holding the railing, use the self-tapping screws and an electric drill to attach the brackets to the underside of the railing.
Note: It is easier with two people; One holding the railing on a flat surface, the other using the drill.
Pre-drilling the holes is not necessary but suggested.

3) Once you have attached your brackets to the railing, use the wall anchor screws and an electric drill to secure the railing brackets to the wall studs.

If you have any questions, please feel free to send us an email at:

arcandhammer@yahoo.com