



How To Install Columbia Forest Products Beaded Panels

Step 1: Prepare the Panels

- Gather the necessary Columbia Forest Products Beaded Panels for installation. To ensure you have the correct number of panels, measure your space prior to purchase.
- Ensure that each panel is properly sized for the area where you intend to install them.



Step 2: Trim Along the Beaded Profile

- Begin by trimming along the beaded profile of the first panel to match the 1.5" spacing required.

- Use appropriate tools, such as a saw, to achieve the desired trim.



Step 3: Trim the Next Panel

- Proceed to the next panel and trim it at the profile to ensure it matches the 1.5" spacing requirement.
- Take care to make precise cuts to maintain consistency.

Step 4: Align the Panels

- Align the trimmed panels on the designated wall or cabinet surface.
- Ensure they fit snugly and are positioned correctly before proceeding.

Step 5: Continue with Installation

- Once the panels are aligned, continue installing them by repeating steps 2 and 3 for each subsequent panel.
- Ensure that the trim at the profile is complete and ready for the next panel before proceeding with installation.

Step 6: Final Checks

- Double-check the alignment and spacing of each panel to ensure a uniform and professional finish.
- Make any necessary adjustments before finalizing the installation.

Step 7: Completion

- Once all panels are installed and aligned correctly, step back and admire your work.
- Enjoy the enhanced aesthetic appeal and functionality provided by Columbia Forest Products Beaded Panels in your space.

