

## **INSTRUCTIONS:**

## Elevated:

- Determine desired location and using template, mark screw locations.
- 2. Drill holes for anchors using a 7/32 in drill bit.
- 3. Install anchors.
- Insert end of threaded rod into number.
- 5. Slide on spacers.
- Align screws with anchors and press into place using a rubber mallet.

## Flush:

- Determine desired location and using template, mark screw locations.
- 2. Drill holes for anchors using a 7/32 in drill bit.
- 3. Install anchors.
- 4. Insert end of threaded rod into number.
- Align screws with anchors and press into place using a rubber mallet.



**MOUNTING TEMPLATE** 

## 180 mm