

Installation

1 Stripping the Speaker Wire

- Select 16AWG to 12AWG speaker wire.
- Strip away the ends of the jacket.



2 Preparing the Banana Plug and Inserting the Wire

- Unscrew the bottom of the banana plug.
- Insert one end of the speaker wire into the (black or red) banana plug and tighten.
- Repeat this step with each banana plug.



3 Preparing for Use

- Ensure the speaker wires are secure in the banana plugs.



4 Ready for Use

- Plug banana plugs into the appropriate receptors.

