



## **CAMPER SEAL FOAM TAPE**

### **Easy to Use:**

**(Leave paper liner on foam during installation)**

- 1. Be sure application surface is clean and dry.  
Temperature should be above 40°F (5°C).**
- 2. Apply tape to bottom of camper shell as tape is unrolled. Do not stretch tape during installation.**
- 3. Remove paper liner.**
- 4. Set camper in place.**