Installation Instructions for Aura Vent, Aura Solar Fan & Pop Vent Retro-Fit Products



* Before you install, make sure that the replacement cap is the right size diameter for your existing base.

Remove the old turbine "head" off the collar. Leave the collar attached to the turbine base on the roof.



Now slide your replacement head over the existing collar

Lastly, use four #8 self-tapping screws to attach the vent's head. Screws should be placed at 12:00, 3:00, 6:00 and 9:00 (Screws not included)









