



1.) No tools are needed.

2.) Remove the existing front plate and endcaps.

3.) Snap on the Baseboarders® endcaps to the Baseboarders® panel and then drop the entire assembly down on to the existing back plate. The 3/4" lip on the back of the Baseboarders® panel will slide down into the gap between the original metal back plate and the wall.

Baseboarders®