



# Forever Dryer Vent Cover



# Installation Instructions

**First**– Measure the opening of your dryer vent. It should be 4 inches.

**Second**– Remove the dryer vent cover from the frame by unscrewing the two screws.

**Three**– Slide the pipe into your dry vent and push it flat to the wall.

**Four**– Using wood screws (if the side of your home is wood) or masonry tapcon screws (if the side of your home is brick or masonry). Drill or screw through the holes of frame. Tighten the screws snug to the frame.

**Five**– Reinstall the dryer vent cover to the frame.