

INSTALLATION GUIDELINES

- 1. Install EVERBILT housewrap over exterior sheathing secured to the wall framing with printed side out. Make sure sheathing is suitable for covering, dry and secured to the framing.**
 - 2. Start from the base of the wall, 2-3 ft from a corner. Unroll EVERBILT housewrap roll along the wall and secure the wrap using large-headed or plastic cap nails or 1 in crown staples as you move around the house. Fasteners should be placed every 12 in to 18 in along the vertical studs and must penetrate the stud or nail base material. Overlap upper layers over lower layers. At least 2 in of overlap should be used for horizontal laps and 6 in for vertical laps.**
 - 3. Cut an inverted "Y" in EVERBILT housewrap to make flaps at door and window openings. Wrap the flaps to the inside of the rough openings and fasten securely. Install flashing over EVERBILT housewrap.**
 - 4. If door or window has been installed, trim EVERBILT housewrap as close as possible and tape the seams around openings.**
 - 5. Use housewrap tape to seal vertical seams.**
-