

# LANDDECOR

## LEDGESTONE PLANTER INSTRUCTIONS

**STEP 1:** Choose (A) if you are installing your planter on **solid ground** (i.e. concrete) or **soft ground** (i.e. dirt) and (B) if you are installing **one** or **two** layers. Continue to the appropriate scenario below.

### SCENARIO 1- SINGLE LAYER ON SOLID GROUND

A) Using **SHORT** fiberglass pins, connect panels in desired planter shape. Push pins down (pointed end first) through each of the hinge holes until pin hits the ground. See *Figure 1* and *Figure 2*. It might be necessary to push the pin down using the flat end of another pin.



*Figure 1*



*Figure 2*

### SCENARIO 2- DOUBLE LAYER ON SOLID GROUND

A) Using **LONG** fiberglass pin, connect panels in desired planter shape. Push pins down (pointed end first) through each of the hinge holes. See *Figure 3*.  
B) Remove 2 pins and set 2 second layer panels at those two joints, then re-insert the pins through each of those hinge holes until pin hits the ground. See *Figure 4* and *5*. It might be necessary to push the pin down using the flat end of another pin. Continue two panels at a time until the second layer is complete.



*Figure 3*



*Figure 4*



*Figure 5*

### SCENARIO 3 - SINGLE LAYER ON SOFT GROUND

- A) Using **LONG** fiberglass pins, connect panels in desired planter shape. Push pins down (pointed end first) through each of the hinge holes until pin hits the ground. See *Figure 6*.
- B) Hammer pins into the ground until the flat end is flush with the top of the panel. See *Figure 7*.



*Figure 6*



*Figure 7*

### SCENARIO 4 - DOUBLE LAYER ON SOFT GROUND

- A) Using **LONG** fiberglass pins, connect panels in desired planter shape. Push pins down (pointed end first) through each of the hinge holes. See *Figure 8*.
- B) Hammer pins into the ground until the flat end of the pin is sticking up above the top of the panel **1 ½ inches** (this step is necessary for the installation of the second layer). See *Figure 9*.
- C) One panel at a time, set the second layer of panels on the lower level by using the 1 ½ inch of pin sticking up at each joint, until the second layer is complete. See *Figure 10*.
- D) Finish stabilizing the second layer by pushing **SHORT** fiberglass pins down (pointed end first) through each of the hinge holes until pin hits the top of the long pin below. See *Figure 11*.



*Figure 8*



*Figure 9*



*Figure 10*



*Figure 11*

**STEP 2:** Fill planter with soil.



**STEP 3:** Place plants in planter!

