

How To Apply

1. Start with thoroughly clean and dry fabric free of soap residue. Follow the manufacturer;s directions to remove all soiling and residue
2. Apply outdoors or in a well-ventilated area
3. Test for colorfastness in small inconspicuous area
4. Spray until item is evenly wet slightly overlapping sprays
5. if drops form on surface, wet a sponge with Aqua Armor and gently wipe drop. Do not allow large drops to dry
6. Allow treated fabric to dry completely. Full sunlight is preferable. Leave out over several days for best results
7. Test for waterproofing by sprinkling water on surface. If protection is not sufficient, a second application may be necessary.