

INSTRUCTIONS:

- ❶ **Prep:** Clean and dry surface. Remove debris. Apply in temps above 40°F.
- ❷ **Fill:** Apply in 1/8" layers with putty knife or spreader. Slightly overfill for proper sanding. Wipe off excess material.
- ❸ **Dry & Sand:** Fills less than 1/4" dry in 2-6 hours; deeper fills may take up to 24 hours. Once dry, sand by hand or with an orbital sander.
- ❹ **Finish:** Paint or stain with latex or oil-based products.
- ❺ **Storage:** Seal lid. Store in a cool and dry space.

PRO TIPS:

- Test stain on scrap before use.
- Seal exterior repairs with paint, stain, or coating.
- Dry time varies with temperature and humidity.



SCAN FOR MORE